

SE-12U300-2.0M	2.0 M Pixel	1600 X 1200
----------------	-------------	-------------

- ◆Interface: USB2.0.
- ◆30 frames/sec (CIF and VGA)
- ◆Focal distance: 3mm - infinity
- ◆Magnification: 1x - 300× adjustable
- ◆USB cable length: 1.5m meters;
- ◆Use for Windows XP, Vista, Windows 7, Windows 8 & MAC
- ◆Add WIFI box, wireless use for Android and Iphone mobile

The pen microscope can be taken off from the stand(if you ask match stand) and hold by hand. It is freely to aim the object in any distance and any directions. Turning the knob is to focus on the object.

SOFTWARE FUNCTIONS

- ◆Image Freeze ◆Snap ◆Video record ◆10 seconds timing snap
- ◆Zoom in & zoom out



ACCESSORIES

PACKING LIST

USB PEN MICROSCOPE	1
WIFI BOX	1
Reflector	1
Multi-function tube	1
Large cap	1
Nose specular	1
Transparent tube	1
Software CD (Software and User's manual included)	1

LIGHT CONTROL & SNAP KEY



SAFETY INSTRUCTIONS

Before using this product, please carefully read the following safety instructions.

1. The socket that the computer is plugged in must be properly grounded, as the computer supplies power to this product. If in any doubt, please have a professional electrician check and verify the grounding to ensure safety.
2. Never use this product in stormy weather.
3. This product contains delicate and precision components. Be gentle when using it and avoid harsh handling or excessive force that may cause damage to the product.
4. The temperature of the handle increases slightly during use and it feels a little warm. This is normal. If the product is overheated and hot to the touch, immediately cut off the power and contact us for repair.
5. Never leave the product on unattended. Unplug from the USB port after use.
6. Do not disassemble this product. Disassembling this product will result in irreparable damage. The company is not responsible for damage resulting from disassemble of the product by the user. In

case of any difficulties in using the product, please contact us.

7. This product may only be used by children under supervision of an adult. Never give this product to a child to use or play by him or herself. Keep this product out of reach of children.

8. Do not let this product come in direct contact with steam, vapor, water, or liquids of any kind. Such contact can cause irreparable damage that is not covered by warranty.

9. When not in use, put the handle in the transparent sleeve and store it in a tightly sealed box to avoid moisture and decay. Damages resulting from improper storage are not covered by the warranty.

10. When using this product for eye examination, the illumination should be as dim and the examination time as short as possible. Never use this product to examine the eyes of infants or young children.

11. Examination or cleaning of the ear canal, nasal cavity and oral cavity should only be undertaken by adults who have mastered the depth and force required for such a task.

12. Never use the mirror or cotton swab for cleaning or treatment of the deep rear part of the oral cavity. Parts may drop into the throat and cause serious damage.

13. The cable of this product has been strictly tested. To ensure safe use, do not replace it.