This is (Electronic Repair Tool portable suction cup 4.3 inch portable LCD digital microscope) a fantastic microscope that provides a good way to share high definition microscopic observation with others. The 4.3 "quality LCD screen provides a vibrant crystal image.

Equipped with a professional microscopic lens, it helps you to easily see small objects. With 250x optical and 4x digital zoom, the magnification can be up to 600x. The rechargeable liion battery of 1050mA offers a stand-alone working time of 2.5-3 hours. The 8 bright LEDs, with adjustable brightness, are bright enough for perfect observation.

With this LCD Digital Microscope you can enjoy your research, or share it with your friends. It is especially useful and affordable for young people to do some basic research, both at home and at school.

#### Main parameters:

1: Pixel: HD 3, 6MP CCD

2: Display: 4.3-inch HD OLED screen.

4: Magnification: 1-600X continuous magnification system.

5: Object distance: 15mm - infinity

6: With built-in lithium battery, Continuously working for 6 hours.

7: Languages: English, Spanish, Russian, Korean, Japanese, Thai, Hebrew, Portuguese, German, French, Italy, Turkey, Czech, Poland, traditional Chinese, Simplified Chinese

>	¢		





- 1:Pixel: HD 3.6MP
- 2:Display: 4.3 inches HD OLED display.
- 3:Magnification: 1-600X continuous magnification system.
- 4:Object distance: 15mm--infinity (Depend on the different distance)
- 5:With built-in lithium battery, available for working more than 6 hours continuously .
- 6:Languages: English, Spanish, Japanese, Korean, Thai, Russian, Hebrew, German, Portuguese,French, Italy, Turkey, Czech, Poland, Traditional/simplified Chinese.

The High-capacity lithium battery needs about 4 hours to be full charged.When it 's charging,the display will show : 7 . when it's full charged,the display will show: 1.

#### Intelligent universal support



The intelligent universal support is super light and powerful, can be adsorbed on the surface of glass/ceramic/marble/plastic board and others.



The silicone sucker will not leave marks on any surface.after long-term using, it can be cleaned by water when there's dust on the surface.



The closest distance of microscope and the goal is -15mm, the magnifying time is the maximum, the magnifying time will be smaller as the distance increasing.



		视频模式
MP	Resolution	分辨率
1	Date Tag	时间标志
	<b>Motion Detection</b>	移动侦测
	Cyclic Record	循环摄像
EV	EV	曝光值
MENU		1/2

-	Rest System	恢复出厂设置
HZ	Frequency	光源频率
The second secon	Filllight	补光灯
B	Video Rotate	图片旋转
1.0	Version	软件版本
		设置
	<b>Format</b>	设置 格式化
ABC		
ABC	Format	格式化
	Format Language Setting	格式化
Ú	Format Language Setting Auto Power-Off	格式化 语言 自动关机



#### (MENU)

Function setting key: Resolution: 1080P, 720P, VGA Date Tag: Displayed /Not displayed Motion Detection: ON/OFF (When it's on it will start to record a video automatically, as soon as detecting something's moving .) Cyclic Record : off/3 minutes /5 minutes /10 minutes.As soon as the memory card's memory is full, it will delete the first video and save the new video automatically. Exposure value: +2.0 (0) -2.0 Format: Yse / NO Automatic shutdown: off, 1 minutes, 3 minutes, Automatic turn off the LCD : off, 1,3,5 minutes Factory Reset: Yes / No

Light source's frequency: 50HZ, 60HZ Time setting: year, month, day, hours, minutes, seconds Image rotating on / off Light: on / off Software version: V1.10

#### MODE

Mode button: Recording Video mode: Taking Photos mode: (5M, 2M, 1.3M, VGA) press OK button for taking photos Playback mode: delete, lock / unlock


### 

Left button, right button,

OK button (photo / video, open key)

Power On/Off

Press it once to turn on, press once again to turn off.



- 1: Power DC interface (5P MINI).
- 2: Memory card's socket (Micro SD), supporting (1-64GB).
- 3: Brightness Adjust button
- 4: REST button, restore the system. (If the machine can not work, please press the button with sharp objects to restart it.)
- 5: Fast loading 4 holes' bayonet, push the bracket's 4 claws into the bayonet, hearing "ka" once, it says the assemble is finished.
- 6: High brightness 8 LEDs, available for up to 100 thousand hours.

## Accessories icon:



Microscope, power supply, data line, multi functional support, user's manual.



QC Inspection

Education purpose inspection

Print Industrial

Industrial Inspection:PCB Material...

Jewellery & Stamp(Collections)

Textile Industrial

**Biological Inspection** 



# Made in China

- ×
- 1 \* Microscope
- 1 \*power supply
- 1 \*data line
- 1 \*user manual

1 \*multifunctional support

