



PIPELINE INSPECTION



CAR INSPECTION



AIR CONDITIONER INSPECTION



SEWER DETECT

Product Features:

WiFi

8.0 m M

640 * 480, 1280 * 720

3.5 m

1 / 5

30fps

70 degree Focal 4-10 CM.

IP67

70

ios

MJPEG

AVI

intraoral, PCB, 30

QR

1. Scain QR

2. wifi Led

(wifi 30)

3. wifi

WiFi

1. WiFi

2. CMOS

支持 JPG 格式 摄像头 AVI 格式 摄像头 摄像头 摄像头 640 × 480, 720 x 1280 摄像头 摄像头 摄像头 摄像头。
 3. 摄像头 1M/2M/3.5M/5M 摄像头, 摄像头 8mm 摄像头 摄像头, 6 摄像头 摄像头 LED 摄像头 摄像头 摄像头 摄像头 摄像头 摄像头 摄像头 摄像头 摄像头 摄像头。

4. 摄像头 摄像头: 摄像头 摄像头 摄像头 摄像头 摄像头 摄像头, 摄像头 摄像头 摄像头, HVAC 摄像头, 摄像头 摄像头, 摄像头 摄像头, 摄像头, 摄像头, 摄像头 摄像头, 摄像头 摄像头, 摄像头 摄像头, 摄像头 摄像头。

摄像头 摄像头:

摄像头, 摄像头 摄像头 QR 摄像头, 摄像头 摄像头 摄像头 摄像头 摄像头 摄像头 摄像头 摄像头 摄像头 摄像头 摄像头;

摄像头, 2 摄像头 摄像头: 摄像头 摄像头 摄像头 摄像头 摄像头 摄像头 摄像头, 摄像头 摄像头 wifi 摄像头 摄像头 摄像头 摄像头 摄像头 摄像头

Product Pictures:



HD 720P 8mm Lens 2.0 Megapixel

1M 2M 3.5M 5M



Support IOS & Android & Windows









IOS



Android



Waterproof



Used on phone

Step One:

(ios)seraach for "wifi view" in the App Store or Scan QR code,and download it.



(android)seraach for "wifi view" in the google play or Scan QR code, and download it.



Step two:

Install wifi view app,then the icon  will show on your phone.

Step three:


Trun on the power swith①,④ the red light will flash.After 10 seconds, the Green light ⑤ keeps on,It indicate that the wifi box works normally.

Step four

Turn Turn on the wifi of the PC,after 15 seconds,and find ZCF of the wifi name.Connect it,password is 12345678,thenThe Green light⑤ will flash.It indicate that the Wifi has connected successfully.Then you can use it.



Step five:

put on the software  . Connect the WIFI Endoscope Camera to ②, the Green light ⑤will flash .Then you can use it.

Used on windows:

Step one:

Scan the QR code to downdoad the software. Or you can download the software by the link : <http://www.zcfkj.com/rar/ZCF99.exe>
We Promise NO VIRUS INCLUDED!!!




Step tow:

Trun on the power swith①,④ the red light will flash.After 10 seconds, the Green light ⑤ keeps on,It indicate that the wifi box works normally.

Step three:

Turn Turn on the wifi of the PC,after 15 seconds,and find ZCF of the wifi name.Connect it,password is 12345678,thenThe Green light⑤ will flash.

Step four

put on the software  . Connect the WIFI Endoscope Camera to ②, the Green light ⑤will flash. It indicate that the Wifi has connected successfully.Then you can use it.



a sucker of gifl for you,Make it easy to use (work on Flat plane)



- 1 x Endoscope
- 1 x Wifi box
- 1 x Small hook
- 1 x Magnet
- 1 x Side mirror
- 1 x Fixed set
- 1 x Sucker
- 1 x Charging line

Product Packaging:

□□ □ □□ x 1

□□ □ x 1

1 □□ x

□□□ □□□ x 1

□□ □ □□ x 1

1 □□ x □□□

□□:□ □□ □□□ □□ □□ □ □□ □□ (1-2 cm).

□□ 1: □□ □□□□ □□ □□ □□□ □□□ □ □ □□□□ □□□□ □□□, □□□.

□□ 2: □ □□□□ □□ □□ □□□ □ □□□□.

□□ 3: □□□ □□ □□ □□ □ □□ □□□ □□□ □ □ □□□ □□□

Approval Certification:



Why Choose US :

Our goal is to provide customers products of high quality, competitive price, and superior services.

- 1.Established in 2005, about 10 years of history;
- 2.Own main factories, supply diversification products and One stop service
- 3.Certificates of ISO9001, UL, CE, EMC,CQC,RoHS,Reach,etc.
- 4.Six years Gold member in Alibaba, Aliexpress etc
- 5.Production capability more than 100 thousands pcs/ month;
- 6.Monthly export more than 50 times delivery;
- 7.Exported to more than 20 countries and regions;
- 8.We provide an excellent combination between prices, quality & respond,delivery,after-sales!

